




## ZENO-WATCH BASEL

### Setting Instruction Unitas


Thank you for purchasing an original ZENO Timekeeper. To ensure correct use, please read these instructions carefully:



### Specifications

Precision Swiss manual-winding movement, time indication, 17 jewels, 21'600 pulsation per hour, Incabloc anti-shock system, Nivaflex spring, tight tolerance of adjustment, power reserve till 40 hours

- A Hour indication
- B Minute indication
- C Second indication



### Setting

- 1 neutral position (unscrew crown first)  
= winding position
- 2 hand setting and second stop position  
- Adjust hour and minute by turning the crown

**Warning:** Be sure to use the watch with the crown pressed in (neutral position).

If your watch has a screw-type crown, be sure to tighten the crown completely. Do not operate the crown with wet fingers or when the watch is wet. Water may enter the watch and compromise water resistance. If moisture has entered the watch, or if the inside to the crystal is fogged up and does not become clear within a day, or seawater enters the watch, immediately take the watch to a Zeno Service Centre for repair. Leaving the watch in such a state will allow corrosion to form inside. Keep your watch clean. Dust and dirt tend to collect in gaps in the back of the case or band. Accumulated dust and dirt may cause corrosion and soil your clothing. Clean the watch occasionally. Use a soft dry cloth to wipe off dirt, perspiration and water from the case and crystal. Do not use the watch in places where it is exposed to high temperature. Doing so may result in deterioration of the watch or parts. Do not place the watch to a magnet. Timekeeping will become inaccurate. Store your watch in a dry place when you are not using it.

**Further information see guarantee card!**

Please be sure to check the ZENO-WATCH internet Web site for the latest listing of World Wide Service Centres at [www.zeno-watch.ch](http://www.zeno-watch.ch)